

~~ADMINISTRATIVE-INTERNAL USE ONLY~~

DATA CENTER OPERATIONS BRANCH

NDS OPERATIONS PROCEDURE MANUAL
NO. P-A006

SYSTEMS SW & HW
13 April 1983

AMPERIF TEST SYSTEM

SYMBOLIC TITLE: N/A
ORIGINATOR:

~~ADMINISTRATIVE-INTERNAL USE ONLY~~

P-A006

DATA CENTER OPERATIONS BRANCH

DCOB SYSTEM SOFTWARE & HARDWARE
OPERATIONS PROCEDURE MANUAL
NO. 50-0008

OPERATION-GENERAL
31 NOVEMBER 1982

AMPERIF TEST SYSTEM

PURPOSE

1. This DCOB System Software & Hardware Operations Procedure Manual establishes the method by which Amperif maintenance personnel will test disks and Disk Control Units. This DCOB Operations Manual will be in affect when Amperif is given the system for the purpose of working on Disk Control Units (i.e., DCA, DCB, DCC, OR DCD).

REFERENCES

2. N/A

PROCESSING

3. All operational disk drives should be put in 'READ ONLY' mode or 'POWERED OFF' for data protection.

4. If Amperif wants the system booted there is a special Amperif Test System that would be booted which consists of a DRS pack (i.e., I.D. - AMPDRS) and any available removeable scratch disk packs that may be needed. These scratch packs have the following labels TEST02, TEST05, TEST08, AMPT03 or AMPT04.

5. The Amperif Test System will be booted using the current operational boot tape with only the necessary Disk Control Units and disk drives. All other Disk Control Units will be put off line at the Multi-Access Subsystem (MAS).

DCOB SYSTEM SOFTWARE & HARDWARE
OPERATIONS PROCEDURE MANUAL
No. 50-0008

OPERATION-GENERAL
1 NOVEMBER 1982

AMPERIF TEST SYSTEM

SYMBOLIC TITLE:
PROGRAMMER :
DATE :
PROJECT NUMBER: